

REQUIRED ITEMS FOR THE SBACH

REQUIRED ITEMS ARE INDICATED BY A CHECKBOX

Radio/ Servos

One transmitter and one receiver:

Futaba 6J 6-channel S-FHSS Transmitter (FUTK6000) and
FUTL7606 Futaba R2006GS 6-Channel S-FHSS Receiver
OR

Tactic TTX660 6-channel SLT Transmitter (TACJ2660) and
TACL0625 Tactic TR625 6-channel Receiver

Four servos:

Futaba S3150 digital servos (FUTM0303)
OR

Futaba S3172SV mini servos (FUTM0125)

Four servo extensions:

Tactic servo extensions for Futaba (TACM2090)
OR

Tactic servo extensions Universal (TACM2092)

12" [300mm] servo extension for the elevator (TACM2093)

Brushless Electric Motor

One motor:

RimFire .32 42-50-800 (GPMG4700)

One propeller:

APC 13 x 8 thin E prop (APCQ3080)
OR

APC 14 x 7 thin E prop (APCQ4145)

One Brushless ESC:

ElectriFly Programmable ESC 80A (GPMM2180)
OR

Castle Creations Phoenix Edge Lite 75 (CSEM1200)
plus { (1) 4mm Female Connector (3) (GPMM3115)
(1) Male Star Connector (HCAM4010)

Battery and Charger

One battery:

Onxy 4S 3300mAh 30C LiPo Battery (ONXP2346)

OR

Onxy 4S 3600mAh 50C LiPo Battery (ONXP3363)

OR

Onxy 4S 3300mAh 70C (ONXP4073)

OR

Venom Fly 4S 3600mAh 30C LiPo Battery (VNRA2516)

OR

Venom Fly 4S 3600mAh 50C LiPo Battery (VNRA2543)

A charger:

Triton EQ2 Programmable Charger (GPMM3156)

* If setting the BEC voltage in the Castle Creations Edge Lite 75 ESC higher than the factory default 5.0V, it is recommended to use a separate BEC regulator such as the Castle Creations 10A BEC regulator (CSEM0005) to power the radio system on-board the aircraft.

SBACH REPLACEMENT PARTS

TOWA5030 Wing
TOWA5031 Fuselage
TOWA5032 Tail Surfaces
TOWA5033 Cowl
TOWA5034 Hatch
TOWA5035 Landing Gear
TOWA5036 Wheel Pants
TOWA5037 Spinner
TOWA5038 Decals
TOWA5039 Wing Tube